

REPLACEMENT PARTS LIST

Indoor Air Handler B5 / GB5 Series




Table of Contents

B5BM Series Multi-Poise Air Handler	3
B5BM-T Series Multi-Poise Air Handler.....	4
B5BM-X Series Multi-Poise Air Handler	5
B5VM Series Multi-Poise Air Handler	6
B5VM-T Series Multi-Poise Air Handler.....	7
B5VM-X Series Multi-Poise Air Handler	8
GB5BM Series Multi-Poise Air Handler	9
GB5BM-T Series Indoor Air Handler	10
GB5BM-X Series Multi-Poise Air Handler.....	11
GB5VM Series Indoor Air Handler.....	12
GB5VM-T Series Indoor Air Handler	13
GB5VM-X Series Multi-Poise Air Handler.....	14
GB5BV-T Series Vertical Air Handler.....	15
B5BM Series (115 Volt) Air Handler	16
B5BV Series Vertical Air Handler	16
B5BMAX Series Multi-Poise Air Handler	16

B5BM Series Multi-Poise Air Handler

ITEM	DESCRIPTION	024KA	024KB	025KA	025KB	030KA	030KB	036KB	037KB	042KB	048KC	049KC	060KC
1	Top Cap Assy	281951R M0023201R	281963R M0023201R	281951R M0023201R	281963R M0023201R	281951R M0023201R	281963R M0023201R	281963R M0023201R	281963R M0023201R	281963R M0023201R	281964R M0023205R	281964R M0023205R	281964R M0023205R
2	Electrical Panel Eff. June 2006	—	—	—	—	—	—	—	—	—	M0023201R	M0023201R	—
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904532	904532	904532
	Control Board Eff. June 2006	—	—	—	—	—	—	—	—	—	904531	904531	—
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
	Complete Blower Assy	904533	904535	904533	904535	904534	904536	904536	904536	904579	904538	904538	904538
7	Complete Blower Assy Eff. June 2006	—	—	—	—	—	—	—	—	—	904537	904537	—
8	Blower Housing	D07481R	D07482R	D07481R	D07482R	D07481R	D07482R	D07482R	D07482R	D07482R	D07484R	D07484R	D07484R
	Blower Housing Eff. June 2006	—	—	—	—	—	—	—	—	—	D07483R	D07483R	—
9	Blower Wheel	667251	667037	667251	667037	667251	667037	667037	667037	667037	667280	667280	667280
	Blower Wheel Eff. June 2006	—	—	—	—	—	—	—	—	—	667207	667207	—
11	Motor, Blower	622257	622257	622257	622257	622264	622258	622258	622258	622260	M0021808R	M0021808R	M0021808R
	Motor, Blower Eff. June 2006	—	—	—	—	—	—	—	—	—	622261	622261	—
12	Kit, Motor Mount	921391	921391	921391	921391	921391	921391	921391	921391	921391	903489	903489	903489
	Kit, Motor Mount Eff. June 2006	—	—	—	—	—	—	—	—	—	921391	921391	—
13	Door Assy	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
15	Replacement Coil (Restrictor change may be needed)	921482	921483	921482	921483	921482	921483	921483	921484	921484	921485	921486	921486
	Distributor Assy (For Tube and Fin Coil)	664195	664196	664197	664198	664200	664201	664203	664203	664203	664207	664207	664209
16	Distributor Assy Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	664288	—
	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
	Fuse, 5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Capacitor, Blwr Mtr (Not Shown)	622535	622535	622535	622535	622550	622545	622545	622545	622545	Not Used	Not Used	Not Used
	Capacitor, Blwr Mtr (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	622549	622549	—
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286803R	286803R	286803R
	Set of Wires (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	286801R	286801R	—

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

B5BM-T Series Multi-Poise Air Handler

ITEM	DESCRIPTION	T24KA	T24KB	T25KA	T25KB	T30KA	T30KB	T36KB	T37KB	T42KB	T48KC	T49KC	T60KC
1	Top Cap Assy	281951R	281963R	281951R	281963R	281951R	281963R	281963R	281963R	281963R	281964R	281964R	281964R
2	Electrical Panel	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023205R	M0023205R	M0023205R
3	Electrical Panel Eff. June 2006	904531	904531	904531	904531	904531	904531	904531	904531	904531	M0023201R	M0023201R	—
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904532	904532	904532
3	Control Board Eff. June 2006	—	—	—	—	—	—	—	—	—	904531	904531	—
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
7	Complete Blower Assy	904533	904535	904533	904535	904534	904536	904536	904536	904579	904538	904538	904538
7	Complete Blower Assy Eff. June 2006	—	—	—	—	—	—	—	—	—	904537	904537	—
8	Blower Housing	D07481R	D07482R	D07481R	D07482R	D07481R	D07482R	D07482R	D07482R	D07482R	D07484R	D07484R	D07484R
8	Blower Housing Eff. June 2006	—	—	—	—	—	—	—	—	—	D07483R	D07483R	—
9	Blower Wheel	667251	667037	667251	667037	667251	667037	667037	667037	667037	667280	667280	667280
9	Blower Wheel Eff. June 2006	—	—	—	—	—	—	—	—	—	667207	667207	—
11	Motor, Blower	622257	622257	622257	622257	622264	622258	622258	622258	622260	M0021808R	M0021808R	M0021808R
11	Motor, Blower Eff. June 2006	—	—	—	—	—	—	—	—	—	622261	622261	—
12	Kit, Motor Mount	921391	921391	921391	921391	921391	921391	921391	921391	921391	903489	903489	903489
12	Kit, Motor Mount Eff. June 2006	—	—	—	—	—	—	—	—	—	921391	921391	—
13	Door Assy	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
15	Replacement Coil	921482	921483	921482	921483	921482	921483	921483	921484	921484	921485	921486	921486
15	TXV Kit (For Replacement coil)	920662A	920662A	920662A	920662A	920663A	920664A	920664A	920664A	920665A	920666A	920666A	920667A
15	Liquid Tube Kit (For Tube and Fin Coil)	921287	921288	921287	921288	921287	921288	921288	921289	921289	921290	921291	921291
15	Distributor Assy (For Tube and Fin Coil)	664256	663830	664256	663830	664257	664219	664219	664219	664219	663583	663583	663586
16	Distributor Assy Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	663586	—
17	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
24	TXV Assy	669550	669550	669550	669550	669552	669553	669553	669553	669554	669555	669555	669556
24	Fuse, 5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Capacitor, Blwr Mtr (Not Shown)	622535	622535	622535	622535	622550	622545	622545	622545	622545	Not Used	Not Used	Not Used
	Capacitor, Blwr Mtr (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	622549	622549	—
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286803R	286803R	286803R
	Set of Wires (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	286801R	286801R	—

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

B5BM-X Series Multi-Poise Air Handler

ITEM	DESCRIPTION	X24KA	X24KB	X25KA	X25KB	X30KA	X30KB	X36KA	X36KB	X37KB	X42KB	X48KB	X48KC	X49KC	X60KC
1	Top Cap Assy	281951R M0023201R	281963R M0023201R	281951R M0023201R	281963R M0023201R	281951R M0023201R	281963R M0023201R	281951R M0023201R	281963R M0023201R	281963R M0023201R	281963R M0023201R	281964R M0023205R	281964R M0023205R	281964R M0023205R	281964R M0023205R
2	Electrical Panel	—	—	—	—	—	—	—	—	—	—	—	—	—	—
3	Electrical Panel Eff. June 2006	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904532	904532	904532	904532
4	Control Board	—	—	—	—	—	—	—	—	—	—	—	—	—	—
5	Control Board Eff. June 2006	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Transformer	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
7	Plate, Element Close-Off	904533	904535	904533	904535	904534	904536	904534	904536	904536	904536	904538	904538	904538	904538
8	Complete Blower Assy	—	—	—	—	—	—	—	—	—	—	—	—	—	—
9	Complete Blower Assy Eff. June 2006	D07481R	D07482R	D07481R	D07482R	D07481R	D07482R	D07481R	D07482R	D07482R	D07482R	D07484R	D07484R	D07484R	D07484R
10	Blower Housing	—	—	—	—	—	—	—	—	—	—	—	—	—	—
11	Blower Housing Eff. June 2006	667251	667037	667251	667037	667251	667037	667251	667037	667037	667037	667280	667280	667280	667280
12	Blower Wheel	—	—	—	—	—	—	—	—	—	—	—	—	—	—
13	Blower Wheel Eff. June 2006	622257	622257	622257	622257	622264	622258	622264	622258	622258	622260	667207	667207	667207	667207
14	Motor, Blower	—	—	—	—	—	—	—	—	—	—	—	—	—	—
15	Motor, Blower Eff. June 2006	921391	921391	921391	921391	921391	921391	921391	921391	921391	921391	903489	903489	903489	903489
16	Kit, Motor Mount	—	—	—	—	—	—	—	—	—	—	—	—	—	—
17	Kit, Motor Mount Eff. June 2006	904553	904554	904553	904554	904553	904554	904553	904554	904554	904555	904556	904556	904556	904556
18	Door Assy	299944R	299945R	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299946R	299946R	299946R	299946R
19	Filler Door	921482	921483	921482	921483	921482	921483	921482	921483	921484	921484	921486	921486	921486	921486
20	Replacement Coil	920668A	920668A	920668A	920668A	920669A	920669A	920670A	920670A	920670A	920671A	920672A	920672A	920672A	920673A
21	TXV Kit (For Replacement coil)	921287	921288	921287	921288	921287	921288	921287	921288	921289	921289	921289	921290	921291	921291
22	Liquid Tube Kit (For Tube and Fin Coil)	664256	663830	664256	663830	664257	664219	664257	664219	664219	664219	664219	663583	663583	663586
23	Distributor Assy (For Tube and Fin Coil)	—	—	—	—	—	—	—	—	—	—	—	—	—	—
24	Distributor Assy Eff. Sept 2006	664663	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664665	664666	664666
25	MC Distributor Assy	669919	669920	669919	669920	669919	669920	669919	669920	669920	669920	669921	669921	669921	669921
26	Drain Pan, Vertical	669855	669855	669855	669855	669855	669855	669855	669855	669856	669856	669857	669857	669857	669857
27	Horizontal Drain Pan Only	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
28	Close-Off	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
29	Ground Lug	669564	669564	669564	669564	669565	669565	669565	669566	669567	669567	669568	669568	669568	669578
30	TXV Assy	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
31	Fuse, 5 AMP (Not Shown)	622535	622535	622535	622535	622550	622545	622550	622545	622545	622545	Not Used	Not Used	Not Used	Not Used
32	Capacitor, Blwr Mtr (Not Shown)	—	—	—	—	—	—	—	—	—	—	—	—	—	—
33	Capacitor, Blwr Mtr (Not Shown) Eff. June 2006	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
34	Coil Support Rod (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
35	Plug, Drain Pan (Not Shown)	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286803R	286803R	286803R	286803R
36	Set of Wires (Not Shown)	—	—	—	—	—	—	—	—	—	—	—	—	—	—
37	Set of Wires (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	—	—	—	—	—

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

B5VM Series Multi-Poise Air Handler

ITEM	DESCRIPTION	024KA	024KB	025KA	025KB	030KA	030KB	036KB	037KB	042KB	048KC	049KC	060KC
1	Top Cap Assy	281963R	281963R	281951R	281963R	281951R	281963R	281963R	281963R	281963R	281964R	281964R	281964R
2	Electrical Panel	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
7	Complete Blower Assy	904539	904540	904539	904540	904539	904540	904540	904540	904540	904541	904541	904541
8	Blower Housing	D07481R	497227	D07481R	497227	D07481R	497227	497227	497227	497227	D07484R	D07484R	D07484R
9	Blower Wheel	667251	667258	667251	667258	667251	667258	667258	667258	667258	667280	667280	667280
11	Motor, Blower	M0021804R	M0021805R	M0021804R	M0021805R	M0021804R	M0021805R	M0021805R	M0021805R	M0021805R	M0021806R	M0021806R	M0021806R
12	Kit, Motor Mount	921391	903489	921391	903489	921391	903489	903489	903489	903489	903489	903489	903489
13	Door Assy	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
15	Replacement Coil (Restrictor change may be needed)	921482	921483	921482	921483	921482	921483	921483	921484	921484	921485	921486	921486
	Distributor Assy (For Tube and Fin Coil)	664195	664196	664197	664198	664200	664201	664203	664203	664205	664207	664207	664209
16	Distributor Assy Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	664288	—
	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
	Variable Speed Control (Not Shown)	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668
	Fuse, 5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Motor Harness (Not Shown)	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632
	Harness, Low Volt (Not Shown)	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

B5VM-T Series Multi-Poise Air Handler

ITEM	DESCRIPTION	T24KA	T24KB	T25KA	T25KB	T30KA	T30KB	T36KB	T37KB	T42KB	T48KC	T49KC	T60KC
1	Top Cap Assy	281963R	281963R	281951R	281963R	281951R	281963R	281963R	281963R	281963R	281964R	281964R	281964R
2	Electrical Panel	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
7	Complete Blower Assy	904539	904540	904539	904540	904539	904540	904540	904540	904540	904541	904541	904541
8	Blower Housing	D07481R	497227	D07481R	497227	D07481R	497227	497227	497227	497227	D07484R	D07484R	D07484R
9	Blower Wheel	667251	667258	667251	667258	667251	667258	667258	667258	667258	667280	667280	667280
11	Motor, Blower	M0021804R	M0021805R	M0021804R	M0021805R	M0021804R	M0021805R	M0021805R	M0021805R	M0021805R	M0021806R	M0021806R	M0021806R
12	Kit, Motor Mount	921391	903489	921391	903489	921391	903489	903489	903489	903489	903489	903489	903489
13	Door Assy	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
15	Replacement Coil	921482	921483	921482	921483	921482	921483	921483	921484	921484	921485	921486	921486
	TXV Kit (For Replacement coil)	920662A	920662A	920662A	920662A	920663A	920663A	920664A	920664A	920665A	920666A	920666A	920667A
	Liquid Tube Kit (For Tube and Fin Coil)	921287	921288	921287	921288	921287	921288	921288	921289	921289	921290	921291	921291
16	Distributor Assy (For Tube and Fin Coil)	664256	663830	664256	663830	664257	664219	664219	664219	664219	663583	663583	663586
	Distributor Assy Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	—	—
17	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664666	664666
	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
24	TXV Assy	669550	669550	669551	669551	669552	669552	669553	669553	669554	669555	669555	669556
	Variable Speed Control (Not Shown)	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668
	Fuse,5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Motor Harness (Not Shown)	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632
	Harness, Low Volt (Not Shown)	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

B5VM-X Series Multi-Poise Air Handler

ITEM	DESCRIPTION	X24KA	X24KB	X25KA	X25KB	X26KB	X30KA	X30KB	X36KA	X36KB	X37KB	X42KB	X48KB	X48KC	X49KC	X60KC
1	Top Cap Assy	281963R	281963R	281963R	281963R	281963R	281963R	281963R	281963R	281963R	281963R	281963R	281963R	281964R	281964R	281964R
2	Electrical Panel	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
7	Complete Blower Assy	904539	904540	904539	904540	904540	904539	904540	904539	904540	904540	904540	904540	904541	904541	904541
8	Blower Housing	D07481R	497227	D07481R	497227	497227	D07481R	497227	D07481R	497227	497227	497227	497227	D07484R	D07484R	D07484R
9	Blower Wheel	667251	667258	667251	667258	667251	667251	667258	667251	667258	667258	667258	667258	667280	667280	667280
11	Motor, Blower	M0021804R	M0021805R	M0021804R	M0021805R	M0021804R	M0021804R	M0021805R	M0021804R	M0021805R	M0021805R	M0021805R	M0021805R	M0021806R	M0021806R	M0021806R
12	Kit, Motor Mount	921391	903489	921391	903489	903489	921391	903489	921391	903489	903489	903489	903489	903489	903489	903489
13	Door Assy	904553	904554	904553	904554	904555	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
	Replacement Coil	921482	921483	921482	921483	920362D	921482	921483	921482	921483	921484	921484	921484	921485	921486	921486
	TXV Kit (Replacement Coil)	920668A	920668A	920668A	920668A	920668A	920669A	920669A	920670A	920670A	920670A	920671A	920672A	920672A	920672A	920672A
15	Liquid Tube Kit (For For Tube and Fin Coil)	921287	921288	921287	921288	921288	921287	921288	921287	921288	921289	921289	921289	921290	921291	921291
	Distributor Assy (For Tube and Fin Coil)	664256	663830	664256	663830	664219	664257	664219	664257	664219	664219	664219	664219	663583	663583	663586
16	Distributor Assy Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664663	664663	664664	664664	664664	664665	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669855	669855	669856	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
24	TXV Assy	669564	669564	669564	669564	669564	669565	669565	669565	669566	669567	669567	669568	669568	669568	669578
	Variable Speed Control (Not Shown)	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668
	Fuse, 5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Motor Harness (Not Shown)	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632
	Harness, Low Volt (Not Shown)	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

GB5BM Series Multi-Poise Air Handler

ITEM	DESCRIPTION	024KA	024KB	025KA	025KB	030KA	030KB	036KB	037KB	042KB	048KB	049KC	060KC
1	Top Cap Assy	281952R	281961R	281952R	281961R	281952R	281961R	281961R	281961R	281961R	281962R	281962R	281962R
2	Electrical Panel	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023205R	M0023205R	M0023205R
	Electrical Panel Eff. June 2006	—	—	—	—	—	—	—	—	—	M0023201R	M0023201R	—
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904532	904532	904532
	Control Board Eff. June 2006	—	—	—	—	—	—	—	—	—	904531	904531	—
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
	Complete Blower Assy	904533	904535	904533	904535	904534	904536	904536	904536	904579	904538	904538	904538
7	Complete Blower Assy Eff. June 2006	—	—	—	—	—	—	—	—	—	904537	904537	—
8	Blower Housing	D07481R	D07482R	D07481R	D07482R	D07481R	D07482R	D07482R	D07482R	D07482R	D07484R	D07484R	D07484R
	Blower Housing Eff. June 2006	—	—	—	—	—	—	—	—	—	D07483R	D07483R	—
9	Blower Wheel	667251	667037	667251	667037	667251	667037	667037	667037	667037	667280	667280	667280
	Blower Wheel Eff. June 2006	—	—	—	—	—	—	—	—	—	667207	667207	—
11	Motor, Blower	622257	622257	622257	622257	622264	622258	622258	622258	622260	M0021808R	M0021808R	M0021808R
	Motor, Blower Eff. June 2006	—	—	—	—	—	—	—	—	—	622261	622261	—
12	Kit, Motor Mount	921391	921391	921391	921391	921391	921391	921391	921391	921391	903489	903489	903489
	Kit, Motor Mount Eff. June 2006	—	—	—	—	—	—	—	—	—	921391	921391	—
13	Door Assy	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
	Replacement Coil (Restrictor change may be needed)	921482	921483	921482	921483	921482	921483	921483	921484	921484	921485	921485	921485
15	Distributor Assy, R22 (For Tube and Fin Coil)	664195	664196	664197	664198	664200	664201	664203	664203	664205	664207	664207	664209
	Distributor Assy, R22 Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	664288	—
16	Distributor Assy, R410A (For Tube and Fin Coil)	664531	664532	664531	664532	664541	664291	664535	664535	664536	664211	664211	664288
	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664665	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
	Fuse, 5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Capacitor, Blwr Mtr (Not Shown)	622535	622535	622535	622535	622550	622545	622545	622545	622545	Not Used	Not Used	Not Used
	Capacitor, Blwr Mtr (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	622549	622549	—
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286803R	286803R	286803R
	Set of Wires (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	286801R	286801R	—

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

GB5BM-T Series Indoor Air Handler

ITEM	DESCRIPTION	T24KA	T24KB	T25KA	T25KB	T30KA	T30KB	T36KB	T37KB	T42KB	T48KC	T49KC	T60KC
1	Top Cap Assy	281952R	281961R	281952R	281961R	281952R	281961R	281961R	281961R	281961R	281962R	281962R	281962R
2	Electrical Panel	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023205R	M0023205R	M0023205R
	Electrical Panel Eff. June 2006	—	—	—	—	—	—	—	—	—	M0023201R	M0023201R	—
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904532	904532	904532
	Control Board Eff. June 2006	—	—	—	—	—	—	—	—	—	904531	904531	—
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
	Complete Blower Assy	904533	904533	904533	904533	904534	904536	904536	904536	904579	904538	904538	904538
7	Complete Blower Assy Eff. June 2006	—	—	—	—	—	—	—	—	—	904537	904537	—
8	Blower Housing	D07481R	D07482R	D07481R	D07482R	D07481R	D07482R	D07482R	D07482R	D07482R	D07484R	D07484R	D07484R
	Blower Housing Eff. June 2006	—	—	—	—	—	—	—	—	—	D07483R	D07483R	—
9	Blower Wheel	667251	667037	667251	667037	667251	667037	667037	667037	667037	667280	667280	667280
	Blower Wheel Eff. June 2006	—	—	—	—	—	—	—	—	—	667207	667207	—
11	Motor, Blower	622257	622257	622257	622257	622264	622258	622258	622258	622260	M0021808R	M0021808R	M0021808R
	Motor, Blower Eff. June 2006	—	—	—	—	—	—	—	—	—	622261	622261	—
12	Kit, Motor Mount	921391	921391	921391	921391	921391	921391	921391	921391	921391	903489	903489	903489
	Kit, Motor Mount Eff. June 2006	—	—	—	—	—	—	—	—	—	921391	921391	—
13	Door Assy	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
	Replacement Coil	921482	921483	921482	921483	921482	921483	921483	921484	921484	921485	921486	921486
15	TXV Kit (For Replacement coil)	920662A	920662A	920662A	920662A	920663A	920663A	920664A	920664A	920665A	920666A	920666A	920667A
	Liquid Tube Kit (For Tube and Fin Coil)	921287	921288	921287	921288	921287	921288	921288	921289	921289	921290	921291	921291
	Distributor Assy (For Tube and Fin Coil)	664256	663830	664256	663830	664257	664219	664219	664219	664219	663583	663583	663586
16	Distributor Assy Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	663586	—
	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
24	TXV Assy	669550	669550	669550	669550	669552	669552	669553	669553	669554	669555	669555	669556
	Fuse, 5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Capacitor, Blwr Mtr (Not Shown)	622535	622535	622535	622535	622550	622545	622545	622545	622545	Not Used	Not Used	Not Used
	Capacitor, Blwr Mtr (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	622549	622549	—
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286803R	286801R	286803R	286803R	286803R
	Set of Wires (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	286801R	286801R	—

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

GB5BM-X Series Multi-Poise Air Handler

ITEM	DESCRIPTION	X24KA	X24KC	X25KA	X25KB	X30KA	X30KB	X36KB	X37KB	X42KB	X48KB	X48KC	X49KC	X60KC
1	Top Cap Assy	281962R	281961R	281952R	281961R	281952R	281961R	281961R	281961R	281961R	281961R	281962R	281962R	281962R
2	Electrical Panel	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023205R	M0023205R
3	Electrical Panel Eff. June 2006	—	—	—	—	—	—	—	—	—	—	M0023201R	M0023201R	—
4	Control Board	9004531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904532	904532
5	Control Board Eff. June 2006	—	—	—	—	—	—	—	—	—	—	904531	904531	—
6	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
7	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
8	Complete Blower Assy	904533	904535	904533	904535	904534	904536	904536	904536	904536	904536	904538	904538	904538
9	Complete Blower Assy Eff. June 2006	—	—	—	—	—	—	—	—	—	—	904537	904537	—
10	Blower Housing	D07481R	D07482R	D07481R	D07482R	D07481R	D07482R	D07482R	D07482R	D07482R	D07482R	—	D07484R	D07484R
11	Blower Housing Eff. June 2006	—	—	—	—	—	—	—	—	—	—	D07483R	D07483R	—
12	Blower Wheel	667251	667037	667251	667037	667251	667037	667037	667037	667037	667037	—	667280	667280
13	Blower Wheel Eff. June 2006	—	—	—	—	—	—	—	—	—	—	667207	667207	—
14	Motor, Blower	622257	622257	622257	622257	622264	622258	622258	622258	622260	622260	—	M0021808R	M0021808R
15	Motor, Blower Eff. June 2006	—	—	—	—	—	—	—	—	—	—	622261	622261	—
16	Kit, Motor Mount	921391	921391	921391	921391	921391	921391	921391	921391	921391	921391	—	903489	903489
17	Kit, Motor Mount Eff. June 2006	—	—	—	—	—	—	—	—	—	—	921391	921391	—
18	Door Assy	904553	904554	904553	904554	904553	904554	904554	904554	904555	904555	904556	904556	904556
19	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
20	Replacement Coil	921482	921483	921482	921483	921482	921483	921483	921484	921484	921484	921485	921486	921486
21	TXV Kit (For Replacement coil)	920668A	920668A	920668A	920668A	920669A	920669A	920670A	920670A	920671A	920672A	920672A	920672A	920673A
22	Liquid Tube Kit (For Tube and Fin Coil)	921287	921288	921287	921288	921287	921288	921288	921289	921289	921289	921290	921291	921291
23	Distributor Assy (For Tube and Fin Coil)	664256	663830	664256	663830	664257	664219	664219	664219	664219	664219	663583	663583	663586
24	Distributor Assy Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	—	663586	—
25	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664664	664665	664666	664666
26	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669920	669921	669921	669921
27	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669856	669856	669856	669857	669857	669857
28	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
29	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
30	TXV Assy	669564	669564	669564	669564	669565	669565	669566	669567	669567	669568	669568	669568	669578
31	Fuse, 5 AMP (Not Shown)	632269	6632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
32	Capacitor, Blwr Mtr (Not Shown)	622535	622535	622535	622535	622550	622545	622545	622545	622545	622545	—	Not Used	Not Used
33	Capacitor, Blwr Mtr (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	—	622549	622549	—
34	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
35	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
36	Set of Wires (Not Shown)	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	—	286803R	286803R
37	Set of Wires (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	—	286801R	286801R	—

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

GB5VM Series Indoor Air Handler

ITEM	DESCRIPTION	024KA	024KB	025KA	025KB	030KA	030KB	036KB	037KB	042KB	048KB	049KC	060KC
1	Top Cap Assy	281952R	281961R	281952R	281961R	281952R	281961R	281961R	281961R	281961R	281962R	281962R	281962R
2	Electrical Panel	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
8	Complete Blower Assy	904539	904540	904539	904540	904539	904540	904540	904540	904540	904541	904541	904541
9	Blower Housing	D07481R	497227	D07481R	497227	D07481R	497227	497227	497227	497227	D07484R	D07484R	D07484R
10	Blower Wheel	667251	667258	667251	667258	667251	667258	667258	667258	667258	667280	667280	667280
11	Motor, Blower	M0021804R	M0021805R	M0021804R	M0021805R	M0021804R	M0021805R	M0021805R	M0021805R	M0021805R	M0021806R	M0021806R	M0021806R
12	Kit, Motor Mount	921391	903489	921391	903489	921391	903489	903489	903489	903489	903489	903489	903489
13	Door Assy	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
15	Replacement Coil (Restrictor change may be needed)	921482	921483	921482	921483	921482	921483	921483	921484	921484	921485	921486	921486
	Distributor Assy (For Tube and Fin Coil)	664195	664196	664197	664198	664200	664201	664203	664203	664205	664207	664207	664209
16	Distributor Assy (Eff. Sept 2006)	—	—	—	—	—	—	—	—	—	—	664288	—
	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
	Variable Speed Control (Not Shown)	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668
	Fuse, 5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Motor Harness (Not Shown)	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632
	Harness, Low Volt (Not Shown)	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

GB5VM-T Series Indoor Air Handler

ITEM	DESCRIPTION	T24KA	T24KB	T25KA	T25KB	T30KA	T30KB	T36KB	T37KB	T42KB	T48KC	T49KC	T60KC
1	Top Cap Assy	281962R	281961R	281952R	281961R	281952R	281961R	281961R	281961R	281961R	281962R	281962R	281962R
2	Electrical Panel	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
7	Complete Blower Assy	904539	904540	904539	904540	904539	904540	904540	904540	904540	904541	904541	904541
8	Blower Housing	D07481R	497227	D07481R	497227	D07481R	497227	497227	497227	497227	D07484R	D07484R	D07484R
9	Blower Wheel	667251	667258	667251	667258	667251	667258	667258	667258	667258	667280	667280	667280
11	Motor, Blower	M0021804R	M0021805R	M0021804R	M0021805R	M0021804R	M0021805R	M0021805R	M0021805R	M0021805R	M0021806R	M0021806R	M0021806R
12	Kit, Motor Mount	921391	903489	921391	903489	921391	903489	903489	903489	903489	903489	903489	903489
13	Door Assy	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
	Replacement Coil	921482	921483	921482	921483	921482	921483	921483	921484	921484	921485	921486	921486
15	TXV Kit (For Replacement coil)	920662A	920662A	920662A	920662A	920663A	920663A	920664	920664A	920665A	920666A	920666A	920667A
	Liquid Tube Kit (For Tube and Fin Coil)	921287	921288	921287	921288	921287	921288	921288	921289	921289	921290	921291	921291
	Distributor Assy (For Tube and Fin Coil)	664256	663830	664256	663830	664257	664219	664219	664219	664219	663583	663583	663586
16	Distributor Assy Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	—	—
	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	281971R	632235	632235	632235	632235
24	TXV Assy	669550	669550	669550	669550	669552	669552	669553	669553	669554	669555	669555	669556
	Variable Speed Control (Not Shown)	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668
	Fuse, 5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Motor Harness (Not Shown)	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632
	Harness, Low Voltage (Not Shown)	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

GB5VM-X Series Multi-Poise Air Handler

ITEM	DESCRIPTION	X24KA	X24KB	X25KA	X25KB	X30KA	X30KB	X36KA	X36KB	X37KB	X42KB	X48KB	X48KC	X49KC	X60KC
1	Top Cap Assy	281952R	281961R	281952R	281961R	281952R	281961R	281952R	281961R	281961R	281961R	281961R	281962R	281962R	281962R
2	Electrical Panel	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R	M0023203R
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531	904531
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
7	Complete Blower Assy	904539	904540	904539	904540	904539	904540	904539	904540	904540	904540	904540	904541	904541	904541
8	Blower Housing	D07481R	497227	D07481R	497227	D07481R	497227	D07481R	497227	497227	497227	497227	D07484R	D07484R	D07484R
9	Blower Wheel	667251	667258	667251	667258	667251	667258	667251	667258	667258	667258	667258	667280	667280	667280
11	Motor, Blower	M0021804R	M0021805R	M0021804R	M0021805R	M0021804R	M0021805R	M0021804R	M0021805R	M0021805R	M0021805R	M0021805R	M0021806R	M0021806R	M0021806R
12	Kit, Motor Mount	921391	903489	921391	903489	921391	903489	921391	903489	903489	903489	903489	903489	903489	903489
13	Door Assy	904553	904554	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299944R	299945R	299944R	299945R	299945R	299945R	299945R	299946R	299946R	299946R
	Replacement Coil	921482	921483	921482	921483	921482	921483	921482	921483	921484	921484	921484	921485	921486	921486
	TXV Kit (For Replacement coil)	920668A	920668A	920668A	920668A	920669A	920669A	920670A	920670A	920670A	920671A	920672A	920672A	920672A	920673
15	Liquid Tube Kit (For Tube and Fin Coil)	921287	921288	921287	921288	921287	921288	921287	921288	921288	921289	921289	921290	921291	921291
	Distributor Assy (For Tube and Fin Coil)	664256	663830	664256	663830	664257	664219	664257	664219	664219	664219	664219	663583	663583	663586
16	Distributor Assy Efr. Sept 2006	—	—	—	—	—	—	—	—	—	—	—	—	—	—
	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664663	664664	664664	664664	664665	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669855	669855	669855	669855	669856	669856	669856	669857	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
24	TXV Assy	669564	669565	669564	669565	669565	669565	669564	669565	669567	669567	669568	669568	669568	669578
	Variable Speed Control (Not Shown)	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668	624668
	Fuse,5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100	669100
	Motor Harness (Not Shown)	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632	634632
	Harness, Low Volt (Not Shown)	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663	634663
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R	286802R

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

GB5BV-T Series Vertical Air Handler

ITEM	DESCRIPTION	T24KA	T24KB	T25KA	T25KB	T30KA	T30KB	T36KB	T37KB	T42KB	T48KC	T49KC	T60KC
1	Top Cap Assy	281952R	281961R	281952R	281961R	281952R	281961R	281961R	281961R	281961R	281962R	281962R	281962R
2	Electrical Panel	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023205R	M0023205R	M0023205R
	Electrical Panel Eff. June 2006	—	—	—	—	—	—	—	—	—	M0023201R	M0023201R	—
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904531	904531	904532	904532	904532
	Control Board Eff. June 2006	—	—	—	—	—	—	—	—	—	904531	904531	—
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate, Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420	226420
7	Complete Blower Assy	904533	904535	904533	904535	904534	904536	904536	904536	904579	904538	904538	904538
	Complete Blower Assy Eff. June 2006	—	—	—	—	—	—	—	—	—	904537	904537	—
8	Blower Housing	D07481R	D07482R	D07481R	D07482R	D07481R	D07482R	D07482R	D07482R	D07482R	D07484R	D07484R	D07484R
	Blower Housing Eff. June 2006	—	—	—	—	—	—	—	—	—	D07483R	D07483R	—
9	Blower Wheel	667251	667037	667251	667037	667251	667037	667037	667037	667037	667280	667280	667280
	Blower Wheel Eff. June 2006	—	—	—	—	—	—	—	—	—	667207	667207	—
11	Motor, Blower	622257	622257	622257	622257	622264	622258	622258	622258	622260	M0021808R	M0021808R	M0021808R
	Motor, Blower Eff. June 2006	—	—	—	—	—	—	—	—	—	622261	622261	—
12	Kit, Motor Mount	921391	921391	921391	921391	921391	921391	921391	921391	921391	903489	903489	903489
	Kit, Motor Mount Eff. June 2006	—	—	—	—	—	—	—	—	—	921391	921391	—
13	Door Assy	904553	904554	904553	904554	904553	904554	904554	904555	904555	904556	904556	904556
	Replacement Coil	921482	921483	921482	921483	921482	921483	921483	921484	921484	921485	921486	921486
15	TXV Kit (For Replacement coil)	920662A	920662A	920662A	920662A	920663A	920663A	920664A	920664A	920665A	920666A	920666A	920667A
	Liquid Tube Kit (For Tube and Fin Coil)	921287	921288	921287	921288	921287	921288	921288	921289	921289	921290	921291	921291
	Distributor Assy (For Tube and Fin Coil)	664256	663830	664256	663830	664257	664219	664219	664219	664219	663583	663583	663586
16	Distributor Assy Eff. Sept 2006	—	—	—	—	—	—	—	—	—	—	663586	—
	MC Distributor Assy	664663	664663	664663	664663	664663	664663	664663	664664	664664	664665	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669919	669920	669920	669920	669920	669921	669921	669921
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235	632235
24	TXV Assy	669550	669550	669550	669550	669552	669552	669553	669553	669554	669555	669555	669556
	Capacitor, Blwr Mtr (Not Shown)	622535	622535	622535	622535	622550	622545	622545	622545	622545	Not Used	Not Used	Not Used
	Capacitor, Blwr Mtr (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	622549	622549	—
	Set of Wires (Not Shown)	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286803R	286803R	286803R
	Set of Wires (Not Shown) Eff. June 2006	—	—	—	—	—	—	—	—	—	286801R	286801R	—
	Fuse, 5 AMP (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269	632269

Please specify Model No., Serial No, and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

B5BM 115 Volt Air Handler

ITEM	DESCRIPTION	025A-A	036A-B	049A-C
1	Top Cap Assy	281951R	281963R	281964R
2	Electrical Panel	M0023204R	M0023204R	M0023204R
3	Control Board	904531	904531	904531
4	Transformer	621807	621807	621807
6	Plate, Element Close-Off	226420	226420	226420
7	Complete Blower Assy	904542	904543	904544
8	Blower Housing	D07481R	D07482R	D07483R
9	Blower Wheel	667251	667037	667207
11	Motor, Blower	622200	622201	621875
12	Kit, Motor Mount	Not Used	Not Used	921391
13	Door Assy	904553	904554	904556
14	Filter Door	299944R	299945R	299946R
15	Replacement Coil (Restrictor change may be needed)	921482	921483	921486
16	Distributor Assy (For Tube and Fin Coil)	664197	664203	664207
	MC Distributor Assy	664663	664663	664666
17	Drain Pan	669919	669920	669921
18	Horizontal Drain Pan	669855	669855	669857
20	Ground Lug	632235	632235	632235
	Fuse, 5 AMP (Not Shown)	632269	632269	632269
	Capacitor, Blwr Mtr (Not Shown)	622545	622545	622550
	Coil Support Rod (Not Shown)	669100	669100	669100
	Plug, Drain Pan (Not Shown)	663351	663351	663351
	Set of Wires (Not Shown)	286801R	286801R	286801R

B5BV Vertical Air Handler

ITEM	DESCRIPTION	000K-B-10	000K-B-15	000K-C-20
1	Top Cap Assy	281961R	281961R	281962R
2	Electrical Panel	M0023202R	M0023202R	M0023202R
3	Circuit Board	904531	904531	904532
4	Transformer	622336	622336	622336
6	Close Off Plate, Element	226420	226420	226420
7	Complete Blower Assy	904549	904549	904538
8	Blower Housing	D07482R	D07482R	D07484R
9	Blower Wheel	667037	667037	667280
11	Motor, Blower	622088	622088	M0021808R
12	Motor Mount Kit	Not Used	Not Used	903489
13	Door Assy	904555	904555	904556
14	Filter Door	299944R	299945R	299946R
20	Ground Lug	632235	632235	632235
23	Circuit Breaker	632249	632249	632249
	Capacitor, Blwr Mtr (Not Shown)	622535	622535	Not Used
	Fuse, 5 AMP (Not Shown)	632269	632269	632269
	Element Assy (Not Shown)	286841	286851	286861
	Element Assy (Not Shown)	—	—	—
	Limit Switch (Not Shown)	626458	626458	626458
	Limit Switch (Not Shown)	—	626487	—
	Element Relay (Not Shown)	622210	622210	622210

Please specify Model No., Serial No., and the correct part number(s) when ordering parts from the nearest authorized dealer or service center.

B5BMAX Series Multi-Poise Air Handler

ITEM	DESCRIPTION	X25K-A	X25K-B	X30K-A	X30K-B	X37K-B	X42K-B	X49K-C	X60K-C
1	Top Cap Assy	281951R	281963R	281951R	281963R	281963R	281963R	281964R	281964R
2	Electrical Panel	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023201R	M0023205R
3	Control Board	904531	904531	904531	904531	904531	904531	904531	904532
4	Transformer	622336	622336	622336	622336	622336	622336	622336	622336
6	Plate,Element Close-Off	226420	226420	226420	226420	226420	226420	226420	226420
7	Complete Blower Assy	904533	904535	904534	904536	904536	904579	904537	904538
8	Blower Housing	D07481R	D07482R	D07481R	D07482R	D07482R	D07482R	D07484R	D07484R
9	Blower Wheel	667251	667037	667251	667037	667037	667037	667207	667280
11	Motor, Blower	622257	622257	622264	622258	622258	622260	622261	M0021808R
12	Kit, Motor Mount	921391	921391	921391	921391	921391	921391	921391	903489
13	Door Assy	904553	904554	904553	904554	904555	904555	904556	904556
14	Filter Door	299944R	299945R	299944R	299945R	299945R	299945R	299946R	299946R
15	Replacement Coil (Restrictor change may be needed)	921482	921483	921482	921483	921484	921484	921486	921486
16	Distributor Assy (For Tube and Fin Coil)	664256	663830	664257	664219	664219	664219	663586	663586
	MC Distributor Assy	664663	664663	664663	664663	664664	664664	664666	664666
17	Drain Pan, Vertical	669919	669920	669919	669920	669920	669920	669921	669921
18	Horizontal Drain Pan Only	669855	669855	669855	669855	669856	669856	669857	669857
19	Close-Off	295471R	295471R	295471R	295471R	295471R	295471R	295471R	295471R
20	Ground Lug	632235	632235	632235	632235	632235	632235	632235	632235
24	TXV Assy	669564	669564	669565	669565	669567	669567	669568	669578
	Fuse, 5 Amp (Not Shown)	632269	632269	632269	632269	632269	632269	632269	632269
	Capacitor, Blower Motor (Not Shown)	622535	622535	622550	622545	622545	622545	622549	Not Used
	Coil Support Rod (Not Shown)	669100	669100	669100	669100	669100	669100	669100	669100
	Plug, Drain Pan (Not Shown)	663351	663351	663351	663351	663351	663351	663351	663351
	Set of Wires (Not Shown)	286801R	286801R	286801R	286801R	286801R	286801R	286801R	286803R

NORDYNE
COMPLETE COMFORT. GENUINE VALUE.

Specifications & illustrations subject to change without notice or incurring obligations. O' Fallon, MO | Printed in U.S.A. (07/11)



708718G (Replaces 708718F)