


# WIRING DIAGRAM

H4HK005H-01A (without circuit breaker)    5kW, 240 VAC, 1-Phase Electric Heater Kit  
 H4HK005H-11A (with circuit breaker)  
 H3HK005H-01A (without circuit breaker)



## NOTES

- 1) Circuit breaker (if supplied) is not wired to heater kit by the factory, see Installation Instructions for wiring procedure.
- 2) If any of the original wire supplied with this unit must be replaced, it must be replaced with wiring material of the same gauge size and temperature rating.
- 3) The installation of this heater kit may require a change in the blower speed tap connection. See Installation Instructions for details.
- 4) Aluminum or copper supply conductors are suitable.

FIELD WIRING	■■■■■■■■■■
FACTORY WIRING	—————
LOW VOLTAGE	—————
HIGH VOLTAGE	—————

710212C (Replaces 710212B)

