

## REPLACEMENT PARTS LIST

LIGHT COMMERCIAL 2-SPEED AIR HANDLER  
FOR USE WITH 7.5 & 10 TON 2-STAGE, SPLIT SYSTEM AC & HEAT PUMPS  
B6TM SERIES



## B6TM LIGHT COMMERCIAL 2-SPEED AIR HANDLER

ITEM	DESCRIPTION	B6TM090-C	B6TM090-D	B6TM120-C	B6TM120-D
		1012991	1012993	1012992	1012994
		208-230/3/60	460/3/60	208-230/3/60	460/3/60
1	PAN, TOP	294071R	294071R	294071R	294071R
2	BRACKET, VERTICAL, DP, RIGHT	293651R	293651R	293651R	293651R
3	PANEL, FRONT, RETURN	294081R	294081R	294081R	294081R
4	BRACKET, VERTICAL, DP, LEFT	293661R	293661R	293661R	293661R
5	COVER, RETURN AIR	292651R	292651R	292651R	292651R
6	PANEL, COIL ACCESS, LF	294121R	294121R	294121R	294121R
7	PAN, DRAIN, VERT, LF	293681R	293681R	293681R	293681R
8	PANEL, FILTER ACCESS, LF	292711R	292711R	292711R	292711R
9	COMPLETE BLOWER ASSEMBLY, 15" x 15"	667285R	667285R	667285R	667285R
10	ADAPTER, FILTER OFFSET	295361R	295361R	295361R	295361R
11	SLIDER, FILTER	295351R	295351R	295351R	295351R
12	PANEL, FILTER RACK, 2 INCH	293621R	293621R	293621R	293621R
14	PANEL, FILTER ACCESS, RT	292761R	292761R	292761R	292761R
15	PAN, BOTTOM	294151R	294151R	294151R	294151R
16	PANEL, BACK	294111R	294111R	294111R	294111R
17	PAN, DRAIN, VERT, RT	293671R	293671R	293671R	293671R
18	PANEL, CLOSE-OFF	294141R	294141R	—	—
	PANEL, CLOSE-OFF	—	—	294142R	294142R
19	MOUNT, ADJUSTABLE MOTOR, 56 FRAME	667367R	667367R	667367R	667367R
20	PANEL, COIL ACCESS, RT	294131R	294131R	294131R	294131R
22	BLOCK, TERMINAL, 8 PIN (NOT SHOWN)	632483R	632483R	632483R	632483R
23	CONTACTOR, 3 POLE 30A (QTY 2)	621667R	621667R	621667R	621667R
24	BOX, ELECTRICAL, TOP/BACK	1013062R	1013062R	1013062R	1013062R
25	SUPPORT, MTR, SLOTTED, H BRACKET	293161R	293161R	293161R	293161R
26	BLOWER MOTOR, 2HP, 2-SPEED	1017611R	1017612R	1017611R	1017612R
27	ADJUSTABLE SHEAVE, MOTOR	667385	667385	667290	667290
28	PULLEY, BLOWER, DRIVE, BK80	667368R	667368R	667368R	667368R
29	BELT, BLOWER DRIVE, A31	669899R	669899R	—	—
	BELT, BLOWER DRIVE, A32	—	—	669676R	669676R
30	COMPLETE COIL ASSY, 090 (TXV/DISTRIBUTOR INCLUDED)	297193R	297193R	—	—
	COMPLETE COIL ASSY, 120 (DISTRIBUTORS INCLUDED, TXV NOT INCLUDED)	—	—	297192R	297192R
31	KEY, BLOWER SHAFT (NOT SHOWN)	618057R	618057R	618057R	618057R
32	RELAY, HIGH / LOW SPEED	624725R	624725R	624725R	624725R
34	TXV, WITH INTERNAL CHECK VALVE (NOT SHOWN)	—	—	1013206R	1013206R
	TXV/DISTRIBUTOR WITH EXTERNAL CHECK VALVE ASSY. (NOT SHOWN)	664556R	664556R	—	—
38	FILTER, PERMANENT (NOT SHOWN)	669654R	669654R	669654R	669654R
40	CAP, CHARGING PORT (NOT SHOWN)	—	—	662102R	662102R
41	CORE, CHARGING PORT (NOT SHOWN)	662103R	662103R	662103R	662103R
42	DISTRIBUTOR, 8 CIR, PART OF COIL ASSEMBLY ITEM 30 - 297192R (NOT SHOWN)	—	—	663586R	663586R
43	FITTING, ACCESS (NOT SHOWN)	663812R	663812R	—	—
44	CAP, SERVICE PORT, BRASS (NOT SHOWN)	663818R	663818R	—	—
45	BOX, ELECTRICAL, BOTTOM/SIDES	1013063R	1013063R	1013063R	1013063R
46	COVER, ELECTRICAL BOX	295411R	295411R	295411R	295411R
47	SWITCH, LIMIT-FREEZESTAT	M0062206R	M0062206R	M0062206R	M0062206R

Please specify the correct Model No., Serial No., and part number(s) when ordering parts from the nearest authorized dealer or service center.

