


REPLACEMENT PARTS LIST

U-CROWN SYSTEM

INDOOR UNIT

GHH12(3.5)KSK4DH

ITEM #	COMPONENT
1	GUIDE LOUVER
2	FRONT PANEL
3	STAND BAR
4	LEFT SIDE PLATE
5	LEFT DECORATIVE BOARD
6	LEFT DRIVING BOX SUB-ASSY
7	DECORATIVE STRIP (UP)
8	COVER PLATE (AIR OUTLET)
9	FILTER SUB-ASSY
10	CROSS FLOW FAN
11	RING OF BEARING
12	O-GASKET SUB-ASSY OF BEARING
13	REAR CASE ASSY
14	EVAPORATOR SUPPORT
15	EVAPORATOR ASSY
16	BREAKWATER
17	WALL MOUNTING FRAME
18	FAN MOTOR
19	CONNECTING PIPE CLAMP
20	DRAINAGE HOSE
21	MOTOR PRESS PLATE
22	ELECTRIC BOX ASSY
23	DETECTING PLATE
24	MAIN BOARD
25	JUMPER
26	SHIELD COVER OF ELECTRIC BOX SUB-ASSY
27	MOUSEPROOF BOARD
28	DISPLAY BOARD
29	AIR LOUVER
30	HELICOID TONGUE SUB-ASSY
31	AIR LOUVER
32	SWING LEVER
33	RIGHT DRIVING BOX SUB-ASSY
34	LOUVER MOTOR SUB-ASSY (LEFT AND RIGHT)
35	RIGHT DECORATIVE BOARD
36	RIGHT SIDE PLATE
37	FRONT CASE ASSY
38	SCREW COVER
39	ELECTRIC BOX COVER SUB-ASSY
40	CONNECTING CABLE
41	POWER CORD
42	REMOTE CONTROLLER



GHH12(3.5)KSK4DH

	PART DESCRIPTION	PART CODE	NORTEK PART NUMBER
1	Guide Louver	1051291601	1025106
2	Front Panel	2002240906	1025061
3	Stand Bar	10582150P01	1032784
4	Left Side Plate	26112361P01	1032785
5	Left Decorative Board	20192600D	1032786
6	Left Driving Box Sub-Assy	20112201	1032787
7	Decorative Strip (UP)	20192602D	1032788
8	Cover Plate (Air Outlet)	20122193P01	1032789
9	Filter Sub-Assy	11122155	1032790
10	Cross FLOW Fan	10352054	1032791
11	Ring of Bearing	26152022	1025099
12	O-Gasket Sub-Assy of Bearing	7651205102	1025107
13	Rear Case Assy	00000100057	1025115
14	Evaporator Support	24212170	1032793
15	Evaporator Assy	01100100177	1032738
16	Breakwater	26112359	1032795
17	Wall Mounting Frame	01252040	1017046
18	Fan Motor	15012466	1032396
19	Connecting Pipe Clamp	2611216401	1028794
20	Drainage Hose	05230014	1028812
21	Motor Press Plate	26112360	1032796
22	Electric Box Assy	10000203761	1041649
23	Detecting Plate	30110133	1032798
24	Main Board	30138000611	1017047
25	Jumper	4202021914	1041650
26	Shield Cover of Electric Box Sub-Assy	01592131	1032800
27	Mouseproof Board	—	—
28	Display Board	30568247	1025060
29	Air Louver	10512336	1032802
30	Helicoid Tongue Sub-Assy	26112560	1032803
31	Air Louver	10512766	1032804

GHH12(3.5)KSK4DH

	PART DESCRIPTION	PART CODE	NORTEK PART NUMBER
32	Swing Lever	none	—
33	Right Driving Box Sub-Assy	20112200	1032806
34	Louver Motor Sub-Assy (Left and Right)	15002021	1032807
35	Right Decorative Board	20192601D	1032808
36	Right Side Plate	26112362P01	1032809
37	Front Case Assy	20022418	1032810
38	Screw Cover	24252029P01	1032811
39	Electric Box Cover Sub-Assy	00001300021	1032812
40	Connecting Cable	—	—
41	Power Cord	—	—
42	Remote Controller	30510568_L58773	1032813
43	Temperature Sensor (Not Shown)	390000595	1032722
44	Temperature Sensor (Not Shown)	390000453	1008342

